uuni

Lighting your Uuni 3

Step 1 Insert the hopper screw halfway as shown above.	Step 2 Insert the pellet slide. There should be a gap of around 3cm between the end of the pellet slide and the wall of the hopper.	Step 3 Place a fire lighter at the front of the burner tray.	Step 4 Arrange approximately one scoop around the fire lighter with pellets.	Step 5 Your burner tray should look like this. Remember not to overfill the tray.
Step 6 Light the firelighter and slide the tray into the burner.	Alternative Step 6 Skip step 3 and use the hole on the side of the burner to light the pellets with a blowtorch.	Step 7 As the pellets start to catch fire add in more pellets.	Step 8 Fill the hopper to around this point.	Step 9 Remember to keep the pellets topped up whilst cooking.

UUNi

Extinguishing your Uuni 3

Step 1 To extinguish the pellets pull out the tray using the handle. We advise wearing a heatproof glove when moving the tray.	Step 2 The embers will still be HOT so be careful removing the the tray.	Step 3 Carefully shake the burned pellets into the water but don't drop the whole tray in.

A couple further notes:

Wind can effect the performance of your Uuni. If possible, find a spot sheltered from wind or point the back of the Uuni upwind. Don't use in high winds.
As with any wood-fired or BBQ product exercise caution when using Uuni, whilst kids love pizza only adults should use Uuni.

If you have any further questions we are always available through our support@uuni.net